

5,000 MILE INTERVAL VEHICLE MAINTENANCE SCHEDULE

SEE BACK FOR MORE ITEMS

ATTENTION: MAINTENANCE AND REPAIR SERVICE PROVIDER
 CONTACT STATE OF UTAH FLEET OPERATIONS AT 855-FLT-UTAH (855-358-8824)
 PRIOR TO WORKING ON STATE OF UTAH FLEET VEHICLES. **ALL SERVICES MUST BE PREAUTHORIZED,**
 YOU MUST HAVE THE VEHICLE ID, MILEAGE, AND DETAILED PARTS AND LABOR PRICING WHEN CALLING.

| MILEAGE | Change oil and oil filter Reset oil life monitor (manufacturer recommended oil, weight & type) | Lubricate chassis, steering, suspension and driveline (grease all zerks) | Check belts, hoses and fill all fluid levels (including DEF) | Drain water from diesel fuel filters | Rotate tires and adjust air pressure | Check brakes | Replace external fuel filters (diesel & gas when light appears or every 15,000 miles) | Replace engine air filter (diesel engine) |
|---------|--|--|--|--------------------------------------|--------------------------------------|--------------|---|---|
| 5,000 | X | X | X | X | X | X | | X |
| 10,000 | X | X | X | X | X | X | | X |
| 15,000 | X | X | X | X | X | X | X | X |
| 20,000 | X | X | X | X | X | X | | X |
| 25,000 | X | X | X | X | X | X | | X |
| 30,000 | X | X | X | X | X | X | X | X |
| 35,000 | X | X | X | X | X | X | | X |
| 40,000 | X | X | X | X | X | X | | X |
| 45,000 | X | X | X | X | X | X | X | X |
| 50,000 | X | X | X | X | X | X | | X |
| 55,000 | X | X | X | X | X | X | | X |
| 60,000 | X | X | X | X | X | X | X | X |
| 65,000 | X | X | X | X | X | X | | X |
| 70,000 | X | X | X | X | X | X | | X |
| 75,000 | X | X | X | X | X | X | X | X |
| 80,000 | X | X | X | X | X | X | | X |
| 85,000 | X | X | X | X | X | X | | X |
| 90,000 | X | X | X | X | X | X | X | X |
| 95,000 | X | X | X | X | X | X | | X |
| 100,000 | X | X | X | X | X | X | | X |
| 105,000 | X | X | X | X | X | X | X | X |
| 110,000 | X | X | X | X | X | X | | X |
| 115,000 | X | X | X | X | X | X | | X |
| 120,000 | X | X | X | X | X | X | X | X |
| 125,000 | X | X | X | X | X | X | | X |
| 130,000 | X | X | X | X | X | X | | X |
| 135,000 | X | X | X | X | X | X | X | X |
| 140,000 | X | X | X | X | X | X | | X |
| 145,000 | X | X | X | X | X | X | | X |
| 150,000 | X | X | X | X | X | X | X | X |

5,000 MILE INTERVAL VEHICLE MAINTENANCE SCHEDULE

SEE BACK FOR MORE ITEMS

| MILEAGE | Replace engine air filter (gasoline engine) | Replace cabin air filter (if equipped) | Replace rear differential fluid (dual rear wheel fullsize van) | Replace differential fluid | Replace transfer case fluid | Transmission Service (no transmission fluid flushing) | Replace spark plugs | Coolant replacement |
|---------|---|--|--|----------------------------|-----------------------------|---|---------------------|---------------------|
| 5,000 | | | | | | | | |
| 10,000 | | | | | | | | |
| 15,000 | | | | | | | | |
| 20,000 | | | | | | | | |
| 25,000 | | | | | | | | |
| 30,000 | X | X | X | | | | | |
| 35,000 | | | | | | | | |
| 40,000 | | | | X | | | | |
| 45,000 | | | | | | | | |
| 50,000 | | | | | | | | |
| 55,000 | | | | | | | | |
| 60,000 | X | X | X | | X | X | | |
| 65,000 | | | | | | | | |
| 70,000 | | | | | | | | |
| 75,000 | | | | | | | | |
| 80,000 | | | | X | | | | |
| 85,000 | | | | | | | | |
| 90,000 | X | X | X | | | | | |
| 95,000 | | | | | | | | |
| 100,000 | | | | | | | | |
| 105,000 | | | | | | | | |
| 110,000 | | | | | | | | |
| 115,000 | | | | | | | | |
| 120,000 | X | X | X | X | X | X | X | X |
| 125,000 | | | | | | | | |
| 130,000 | | | | | | | | |
| 135,000 | | | | | | | | |
| 140,000 | | | | | | | | |
| 145,000 | | | | | | | | |
| 150,000 | X | X | X | | | | | |